



TECHNICAL DATA SHEET

PP-1550

**PARAGLAZE
MULTIPRIME**

PRODUCTS

Paraglaze Multiprime
Paraglaze Hardeners
Paraglaze Reducers

PP-1550
PH-4100 or PH-4200
PS-6100 or PS-6200 or PS-6300

PRODUCT DESCRIPTION

Paraglaze Multiprime is a two pack acrylic urethane primer. Multiprime is mainly used as a primer surfacer or wet on wet primer, however it can also be used as a primer filler, it offers excellent surface levelling, sanding and gloss holdout. It is specifically designed for application under Protec 606 line acrylic urethane enamels & 706 line Paraglaze basecoat. For large areas of bare metal use Protec Etch or Epoxy Primer under Multiprime. This product can be tinted with 606 line solid colour tinters up to a maximum of 10%.

SUBSTRATES & PREPARATION



Fully cured 2 pack refinish coatings that have been degreased and sanded.

Sound Automotive OEM coatings that have been degreased and sanded.


Small areas of bare metal that have been degreased and sanded.

Electrocoated new panels that have been degreased and sanded.

GRP Fibreglass that has been degreased and sanded.

Large areas of bare metal and areas where polyester body filler will be applied should be coated first with Protec Epoxy Primer AP-4110.

MIXING RATIO BY VOLUME



PRODUCT


PP-1550
PH-4100 or PH-4200
PS-6100 or PS-6200 or PS-6300

PARTS

4
1
10-30%


**If tinting: Add up to 10% of 606 line tinter before adding hardener
In wet on wet mode use 4-1-30%**

POTLIFE




1 hour at 20°C

SPRAY VISCOSITY @ 20°C



18-23 Seconds (DIN4)

SPRAYGUN SETUP



1.6mm - 1.8mm

SPRAY PRESSURE

HVLP / RP

2 – 3 bar

CONVENTIONAL

45 – 55 PSI / 300-380 KPA

NUMBER OF COATS & FLASH OFF



1st coat

Flash off

2nd coat

Flash off

3rd coat

(If required)

1-2 coats

Flash off

Primer Filler Mode

Apply an even medium coat

5 Minutes at 20c

Apply an even wet coat

5 Minutes at 20c

Apply an even wet coat

Wet on Wet Mode

Apply an even wet coat or coats

10-15 Minutes at 20c


Must be topcoated within 45 minutes when using as a wet on wet.

DRYING TIMES



Bake Temperature

65 °c



Bake Time

40 Minutes

IR Time

10-14 Minutes (short wave)

Air Dry Time

Air dry overnight at 20c

Temperature shown is metal temperature

TOTAL DRY FILM BUILD

130 - 160 um

SANDING DRY

Finish with no coarser than P500 Dry



SANDING WET

Finish with no coarser than P800 Wet

OVERCOAT WITH

Multiprime can be topcoated with Protec 606 line acrylic urethane enamels & 706 line Paraglaze basecoat.

Note: This product must be topcoated within 72 hours. The vehicle must be kept dry and free of moisture and contaminants during this period.

EQUIPMENT CLEANING

After use, clean all equipment thoroughly with cleaning solvent or thinner.

HEALTH AND SAFETY

Please refer to Material Safety Data Sheets for full Health and Safety details.

Paraglaze Hardeners and activated products contain isocyanate and therefore particular safety precautions must be taken.

Goggles must be worn when mixing and using to prevent accidental splashing into the eye. If contact occurs with eyes give prolonged irrigation with water and get medical attention immediately.

Good ventilation and extraction must be provided in the working environment.

Wear suitable protective equipment to prevent skin contact with this material.

When spraying this product the operator (and persons in vicinity) must wear suitable air-fed breathing apparatus. Do not smoke whilst using this material.

This product is for professional use only.
The information given in this sheet is for guidance only. Any person using the product without first making further inquiries as to the suitability of the product for the intended purpose does so at his own risk and we can accept no liability for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.
Drying times quoted are average times at 20°C/68°F. Film thickness, humidity and shop temperature can all affect drying times.

Before using refer to Material Safety Data Sheet obtainable from Protec Pty Ltd.

Follow all directions and warnings fully and carefully. Otherwise do not use this product

Protec Pty Ltd. 97-105 Bedford Street, Gillman, S.A. 5013 Australia

EMERGENCY RESPONSE NUMBER: Australia: 1800 883 254

Protec Pty Ltd. 5 Monahan Rd, Mt Wellington, Auckland, New Zealand

EMERGENCY RESPONSE NUMBER: New Zealand: 0800 000 096